3 Easy Steps for Best Driveway Sealing Results

STEP 1: TRIM AND CLEAN SURFACE

a. Sweep entire surface, removing grass cuttings and other debris. Scrape clean all cracks using a screwdriver.

b. Trim grass and bushes away from driveway.

c. Scrub gasoline and oil stains with undiluted Driveway Kleen™ and a wire brush. Shoot stream of water into cracks and flush clean.

d. Wash entire driveway with Driveway Kleen. Then rinse entire driveway surface with clean water.

STEP 2: REPAIR CRACKS AND HOLES

a. Fill cracks up to ½" wide with Black Jack Speed-Fill Crack Filler.

b. For expanding cracks or climates with wide ranges in seasonal temperatures, fill cracks up to ½" wide with Black Jack Speed-Fill Elastic Crack Filler.

c. Repair large cracks, deteriorated surfaces,, and small holes up to 1" deep with Black Jack Speed Patch. Apply with trowel, tapering into existing surface.

d. For holes larger & deeper than 1", use Ready Road Repair Pot Hole Patch. Use tamper to pack material tight into repair. Ready for traffic immediately. Allow to cure a minimum of thirty days prior to seal coating.

PROJECT HOW-TO'S™ COPYRIGHT © 2005 - 2012, GARDNER-GIBSON, INC.